

Lane Line Instructions

- Place the lane line reel close to the lane line you will be removing or replacing near the edge of the pool and set the brakes. Be careful when steering the reel to not push the reel into the pool.

Removal of Lane Lines

1. Using the wrench from the guard shack, tighten the lane line just a little bit and press the lever to release the tension.
2. Unhook the lane line from the opposite side of the pool.
3. Using the wrench tighten the lane line to get rid of the slack before placing in on the lane line reel.
4. Hook the lane line onto the eye hook on the lane line reel.
5. Roll up the lane line onto the reel evenly and with no gaps.
6. When removing more than one lane line, follow the same steps listed above and then hook the next lane line on the reel using the hooks on both lane lines.
 - a. Do not hook the next lane line on the floats of the lane line already on the reel.

Replacing Lane Lines

When replacing lane lines be careful to not pull the lane line reel into the pool. Make sure the lane line reel brakes are set.

1. Start walking along the edge of the pool pulling the lane line with you.
2. As you approach the end of the lane line on the reel, stop pulling and leave the lane line on the deck.
3. Unhook the lane line from the reel.
4. Release the slack on the lane line and attach the hook to the eye hook on the wall in the pool.
5. Go back to the end you left on the deck and pull it to the eye hook on the other end of the pool.
6. Attach the hook to the eye hook in the pool.
7. Using the wrench in the guard shack, tighten the slack on the lane line until it is straight and taught.
 - a. The lane line should not move in a wave pattern when people swim by.
 - b. Do not overtighten lane lines as removal will be more difficult.
8. Repeat as necessary.